

catoolRT 18.12 Release Notes

Changes since 18.9:

- AK will not change to online or recording mode if certain configuration windows are open in the GUI
- Fix some occurrences of engine database not changing when existing engine selected
- Add "Marker Every" property to plot format
- "File" -> "Open Data" is now "Data" -> "Open Data"
- "File" -> "Close"/"Close All" is now "Data" -> "Close"/"Close All"
- "File" -> "Save Data" is removed
- "File" -> "Save Data As" is now "" -> "File" -> "Save Acquisition As"
- "Acquisition" -> "Reload Acquisition" is now "File" -> "Open Acquisition"
- Removed "Freeze Cycle" logic. Icon in far right hand side of status bar indicates AK (remote) protocol active
- Calculate maximum delay time to transmit XCP information
- Improvements to "Import & Export" functionality
 - o Importing TFX CSV data
 - o Importing raw CSV data
- Improvements to batch processing functionality
- Improvements to print scaling
- Plot frequency based data loaded from AVL IFile
- Speed improvements to FFT, filtering and data acquisition
- Calculate FFT of knock pressure and angular torque sum
- Enable cursors on time axis plots
- Crash robustness when copying data to clipboard
- Plot markers on time based data
- Centre message box on screen if main window is closed
- Configure default clipboard size in "File" -> "Properties"